

SX58

stringing instructions

EXO³ WARRIOR TEAM WARRIOR 1000

Pattern: 10M x 14X

Main String:

- Start Mains at top
- Skip 7H, 9H and 10H
- Grommets at 5H, 6H and 11H have 2 holes in a single barrel
- 1 string per hole required.

Cross String:

- Start Crosses at 5H
- Bottom Crosses at 5T.

Tie Off:

- Mains at 4H and 8H
- Crosses at 6T.

Prince requires:

The cross strings to be installed from the top on all racquets. Installing crosses starting from the bottom will void the warranty.

