A

Section view A-A Scale: 1:3

This document and the contained informations are exclusive property of PRINCE SPORTS SRL, and the proprietary and confidential. Neither this document nor any of the information contained in it may be used for any purpose what so ever, nor reproduced or disclosed by you to others, except with the express prior written consent of PRINCE SPORTS SRL

Proprieta` PRINCE SPORTS SRL e` vietato qualsiasi uso o riproduzione non autorizzati di questo disegno. PRINCE SPORTS SRL ALL RIGHT RESERVED

## 3 REVISION

## KEY

M = Main String

X = Cross String

H = Head (top)

T = Throat

L = Left Side

R = Right Side

SS= Short Side

2PR = 2 Piece stringing required

2PO = 2 piece stringing option

Length: TBD

Tension: 29 - 35 lbs

SX47\_ 75 12M 17X Pattern : 12M x 12X

Mains course 1: up at hole 1(left), go down to hole 29, up through hole 28 to hole 2(left), come back down through hole 3 (left) to hole 27, then go up through hole 26 to hole 4 (left), downthrough hole 5 (left) to hole 25 then up through hole 23 to hole 6 (left) and go to the tie off, hole 5 (left).

Mains course 1: up at hole 1(right), go down to hole 29, up through hole 28 to hole 2(right), come back down through hole 3 (right) to hole 27, then go up through hole 26 to hole 4 (right), downthrough hole 5 (right) to hole 25 then up through hole 23 to hole 6 (right) and go to the tie off, hole 5 (right).

1 string per hole required.

Tie Off: M's at 5H

X's at 24(left),6H (right)

## Notes:

Prince requires X's to be installed from top to bottom on all racquets. Beware bottom to top installation of X's will void the warranty.

In order to make it easier to feed cross strings through channels previously covered by main strings, it is recommended to place a piece of scrap string across the string groove prior to pulling tension on the main string. This string can then be used to pull the main string to the side when installing the cross string, and then removed from the racquet.

## CAUTION:

MORE PERFORMANCE racquet design is unique because they do not need plastics grommets to protect the strings.It is not recommended to use sharp object such as awls during stringing because of the potential to scratch or damage the racquet frame



PROPRIETA' PRINCE SPORTS SRL E' VIETATO QUALSIASI USO O RIPRODUZIONE NON AUTORIZZATI DI QUESTO DISEGNO SX47\_75 STRINGING INSTRUCTION

66.666.151



00

PRINCE SPORTS SRL'S INDUSTRIAL PROPERTY EVERY UNAUTHORIZED USE OR REPRODUCTION OF THIS DRAWING IS PROHIBITED