



This document and the contained informations are exclusive property of PRINCE SPORTS SRL, and the proprietary and confidential. Neither this document nor any of the information contained in it may be used for any purpose what so ever, nor reproduced or disclosed by you to others, except with the express prior written consent of PRINCE SPORTS SRL

Proprieta' PRINCE SPORTS SRL e' vietato qualsiasi uso o riproduzione non autorizzati di questo disegno.  
PRINCE SPORTS SRL ALL RIGHT RESERVED

**prince**®

PROPRIETA' PRINCE SPORTS SRL E' VIETATO QUALSIASI USO O RIPRODUZIONE NON AUTORIZZATI DI QUESTO DISEGNO

Codice Descriz.

SC50A  
STRINGING INSTRUCTION

66.666.182

Indice  
modifica

00

PRINCE SPORTS SRL'S INDUSTRIAL PROPERTY EVERY UNAUTHORIZED USE OR REPRODUCTION OF THIS DRAWING IS PROHIBITED

## REVISION

## KEY

M = Main String  
X = Cross String  
H = Head ( top )  
T = Throat  
L = Left Side  
R = Right Side  
SS= Short Side  
2PR = 2 Piece stringing required  
2PO = 2 piece stringing option

Length : TBD (1PR)

Tension : 29 - 35 lbs

SC50A 16M 16X

Pattern : 16M x 16X

Start M's at Head.

M's skip holes 7, 9 and 10.

Holes 5 and 8 are share holes.

X's start at 5R. Last X at 21L.

Tie Off : M's at 8  
X's at 19 (left), 6 (left)

## Notes:

Prince requires X's to be installed from top to bottom on all racquets. Beware bottom to top installation of X's will void the warranty.

In order to make it easier to feed cross strings through channels previously covered by main strings, it is recommended to place a piece of scrap string across the string groove prior to pulling tension on the main string. This string can then be used to pull the main string to the side when installing the cross string, and then removed from the racquet.

## CAUTION:

MORE PERFORMANCE racquet design is unique because they do not need plastics grommets to protect the strings. It is not recommended to use sharp object such as awls during stringing because of the potential to scratch or damage the racquet frame