

STRINGING INSTRUCTIONS



Recommended Stringing Technique OPTION A

MODEL : TX174-105
PATTERN : 16M x 19X
LENGTH : TBD (2PO)

M' STRING

Start M's at head. M's skip 7H, 9H, 7T, 9T. No shared holes.

X' STRING

Cross string channels are not symmetrical

LEFT SIDE have 7 small string holes
RIGHT SIDE have 6 small string holes

Start X's at 7H RIGHT SIDE

Bottom X at 7T


For this stringing option (if you use the stringing machine without brake) please follow carefully:

- 1- from the third last cross string pass directly to the last cross position
- 2- insert the string into the last cross position and pay attention to start the alternative passage of the cross string cross the main string following the same order of the last third cross string. Do not pull the string, yet.
- 3- pass the string in the second last cross position and pay attention to the starting order of the stringing
- 4- at end pull the last and the second last cross string together
- 5- close the t-off as usual

TIE OFF

X's at 8T LEFT SIDE and 10H RIGHT SIDE as suitable on the racquet

M's at 8H LEFT SIDE and RIGHT SIDE as suitable on the racquet



Vibration Dampener MUST be removed from throat area of frame BEFORE stringing. Once stringing is complete, vibration dampener may be re-attached.

PRINCE requires X'S to be installed at top of all raquets. Bottom to top installed X's will void warranty.

CAUTION: Cross string starting knot is not symmetrical . O3 racquet designs are unique because they do not need plastics grommets to protect the strings. It is not recommended to use sharp object, such as awls, during stringing because of the potential to scratch or damage the racquet frame.

This document and the contained informations are exclusive property of PRINCE SPORTS SRL, and the proprietary confidential. Neither this document or any of the information contained in it may be used you for any purpose what so ever; nor reproduced or disclosed by you to others, except with the express prior written consent of PRINCE SPORTS SRL.

7TW62-SI

STRINGING INSTRUCTIONS



Alternate Stringing Technique OPTION B

MODEL : TX174-105
PATTERN : 16M x 19X
LENGTH : TBD (2PO)

M' STRING

Start M's at head. M's skip 7H, 9H, 7T, 9T. No shared holes.

X' STRING

Cross string channels are not symmetrical

LEFT SIDE have 7 small string holes
RIGHT SIDE have 6 small string holes


Start X's at 7H RIGHT SIDE

Bottom X at 7T

TIE OFF

X's at 8T LEFT SIDE and 10H RIGHT SIDE as suitable on the racquet

M's at 8H LEFT SIDE and RIGHT SIDE as suitable on the racquet



Vibration Dampener MUST be removed from throat area of frame BEFORE stringing. Once stringing is complete, vibration dampener may be re-attached.

PRINCE requires X'S to be installed at top of all raquets. Bottom to top installed X's will void warranty.

CAUTION: Cross string starting knot is not symmetrical . O3 racquet designs are unique because they do not need plastics grommets to protect the strings. It is not recommended to use sharp object, such as awls, during stringing because of the potential to scratch or damage the racquet frame.

This document and the contained informations are exclusive property of PRINCE SPORTS SRL, and the proprietary confidential. Neither this document or any of the information contained in it may be used you for any purpose what so ever; nor reproduced or disclosed by you to others, except with the express prior written consent of PRINCE SPORTS SRL.